




Right red light is blinking
RS485 mode – offline state
(not communicating with Master Unit)



No lights on top
RS485 mode – online state




Solid green lights on top
Reader is in door open state




End lights blinking multicolor
RS485 or SDU mode –
requesting a PIN




Middle red lights blinking
RS485 or managed mode –
reader is in sync with Master Unit




Solid red lights on top
Wiegand, managed or SDU
mode – online state



Alternating red-green rows
Wiegand or managed mode –
requesting a PIN



Solid reds; right light blinking
Managed mode – offline state



Solid reds; left light blinking
SDU mode – offline state